


# **LED Solar Light**



Phoenix, AZ 85029 www.nltubular.com www.solaratticfan.com 800.363.9865














WARNING: Please take the time to read through the ENTIRE instructions prior to starting any work. Not following the instructions will invalidate the warranty.

www.nltubular.com

### PROCESS








#### STEPS

- 1. Install rechargeable batteries into the LED Light
- 2. Remove diffuser
- 3. Locate light pipe rim
- 4. Attach supplied hook
- 5. Attach LED Light to hook
- 6. Turn ON/OFF switch to on position
- 7. Re-install the diffuser

#### BATTERY REPLACEMENT

Requires (2) AA 2300mAH batteries





## STORAGE

During prolonged storage, turn switch to OFF position and remove the batteries.





### **Caution:**

Please use caution when handling product as it may have sharp edges. Only use rechargeable batteries with this product. (Wear gloves) Please make sure the fixtures are firmly installed before use.